


PSYCHOACOUSTIC VIBRATION TRANSDUCER

THREADING THE PVT



- 1 - Put the thread into the slot and adjust the thread length.
- 2 - Wrap the free end of the thread around the straw and into the slot again.
- 3 - Cut off the excess thread leaving a half inch or so.

SPACING AND THREAD LENGTH

