


FLUX OF  $\vec{E}$ - FIELD: GAUSS' LAW

We have used the analogy of water flowing into (out of) a sink (source) to imagine the  $\vec{E}$ - field surrounding a point charge.



Just as we talk of the amount of water flowing through an area, we now talk of the FLUX of  $\vec{E}$  as the quantity

$$\Delta \Phi_E = \vec{E} \cdot \Delta \vec{A} = E \Delta A \cos(\vec{E}, \hat{n})$$

as a measure of the "amount" of  $\vec{E}$ - field "flowing" out of or into a surface of area  $\Delta A = \Delta A \hat{n}$


Example

Take area  $\Delta A$  lying in  $xy$ -plane

$$\Delta \vec{A} = \Delta A \hat{n}$$

$$= \Delta A \hat{z}$$

$$\text{Take } \vec{E} = E_y \hat{y} + E_z \hat{z}$$



**NOTICE:**

*FLUX Is MAXIMUM*

when  $\vec{E} \parallel \hat{n}$ .

*FLUX Is ZERO*

when  $\vec{E} \perp \hat{n}$

Thus

$$\Delta\Phi_E = E\Delta A \cos(E, \hat{z})$$


or

$$\Delta\Phi_E = (\Delta A)E_z$$

That is only component of  $\vec{E}$  parallel to  $\hat{z}$  contributes to flux of  $\vec{E}$  through  $\Delta A$ . [To go through a door you must travel along its normal]

Example:

Consider a cube. Let  $\vec{E} = E\hat{x}$



NO SOURCE OR SINK INSIDE CUBE

Flux of  $\vec{E}$  is non-zero only over faces ABCD and FGHK.

Over ABCD flux is into Cube

Over FGHK flux is out of Cube

TOTAL FLUX THROUGH CUBE=0 AS IT MUST BE BECAUSE THERE IS NO SOURCE OR SINK INSIDE IT. EVERY LINE THAT COMES IN MUST LEAVE [LINES STOP (START) AT SINKS (SOURCES) ONLY].

So it is not surprising that Gauss' Law says: THE TOTAL FLUX OF THE  $\vec{E}$ -FIELD THROUGH A CLOSED SURFACE IS DETERMINED SOLELY BY THE SOURCES (+CHARGES) AND SINKS (-CHARGES) IN THE VOLUME ENCLOSED BY THE SURFACE.

$$\text{Mathematically, } \sum_c \vec{E} \cdot \Delta \vec{A} = \sum_c E \perp \Delta A = \frac{1}{\epsilon_0} \sum Q_i \quad (1)$$


$$\text{Where } \frac{1}{4\pi\epsilon_0} = k_e = 9 \times 10^9 \frac{N \cdot m^2}{C^2}, \epsilon_0 = 9 \times 10^{-12} \frac{F}{m}$$

The  $\sum_c$  on the left hand side is sum of the flux over all parts of the closed surface.  $\sum Q_i$  is the algebraic sum of all the enclosed charges.

Example:

In general, Gauss' law would be very difficult to use to calculate  $\vec{E}$ . All it can give us is the total flux once the  $Q_i$ 's are known. Here are 4 charges. If you draw any surface enclosing all of them we can write down the total flux of  $\vec{E}$  immediately.

$S_1, S_2, S_3$  are any three closed surfaces drawn around our four charges. In each case



$$\begin{aligned} \sum_c \vec{E} \cdot \Delta \vec{A} &= \frac{1}{9 \times 10^{-12}} [5 \times 10^{-6} + 12 \times 10^{-6} - 6 \times 10^{-6} - 13 \times 10^{-6}] \\ &= -2.2 \times 10^5 \frac{N \cdot m^2}{C} \end{aligned}$$

but it tells you nothing about the  $\vec{E}$ -field at any point on any surface.

However, there are some special cases where we can use this law to calculate  $\vec{E}$ -field in one step. [Please look at notes from Phys 121 to recall similar results for Gravitational field.]

The calculation depends crucially on recognizing the symmetry of the problem and choosing the Gaussian Surface in such a way that the sum on the left of Eq. 1 can be calculated right away.

Example 1:

Point charge  $+Q$  located at the origin,  $r=0$ . Because of spherical symmetry about  $r=0$ , the  $\vec{E}$ -field cannot depend on angle. It must be radial (*along  $\hat{r}$* ) and be a function of  $r$  only. We should choose for our surface a sphere of radius  $r$  centered at  $r=0$ . Then I)  $E$  has the same magnitude at all points on the surface of the sphere and II)

$$\vec{E} \cdot \vec{\Delta A} = E(r) 4\pi r^2 = \frac{Q}{\epsilon_0}$$

because

$$\vec{E} \parallel \hat{r} \text{ everywhere so } \vec{E} \cdot \hat{n} = E$$


$$\vec{E} = \frac{Q}{4\pi\epsilon_0 r^2} \hat{r} = \frac{k_e Q}{r^2} \hat{r}$$

Example 2:

$-|Q|$  Located at  $r=0$ . Again  $\vec{E}$  can only be a function of  $r$  and directed along

$$-\hat{r} \text{ so (FLUX is inward) } -E \cdot 4\pi r^2 = \frac{-|Q|}{4\pi\epsilon_0}$$

$$\vec{E}(r) = \frac{-|Q|}{4\pi\epsilon_0} \hat{r}$$




Example 3:

Long Line of charge:  $\lambda$  C/m along  $\hat{z}$ . Now there is cylindrical symmetry about z-axis.

Field cannot depend on  $z$ .


Field cannot depend on Angle.


Must be a fn of  $r$  only and directed along  $r$ .



Choose as surface cylinder of length  $L$ , radius  $r$ , axis of cylinder on  $z$ -axis.

Then  $\sum_c \vec{E} \cdot \Delta \vec{A} = E(r)2\pi rL$ . No contribution from End surfaces as  $\vec{E}$  is parallel to them.





Also

$$\sum Q_i = \lambda L$$


so

$$E(r) \cdot 2\pi r L = \lambda L$$

$$\vec{E}(r) = \frac{\lambda}{2\pi r \epsilon_0} \hat{r}$$

Example 4:

Hollow sphere (spherical shell) has charge  $+Q$  on its surface, radius  $R$  and is centered at  $r=0$ . Again symmetry about  $r=0$ , requires that  $\vec{E} \parallel \hat{r}$  and is a function  $r$  only.



First, consider  $r < R$ . Choose any surface through  $r$ .  $r < R \implies \sum_c \vec{E} \cdot \Delta A = 0 \implies$  No enclosed charge.

If  $\sum_c \vec{E} \cdot \Delta A = 0$  for any and every surface as long as  $r < R$ , it implies  $\vec{E} = 0$

If  $r > R$ ; the appropriate surface is a sphere of radius  $r$  and now  $\Sigma_c \vec{E} \cdot \Delta \vec{A} = E(r) 4\pi r^2$


Hence,

$$\begin{aligned} \vec{E} &= \frac{Q}{4\pi\epsilon_0 r^2} \hat{r} \\ &= \frac{k_e Q}{r^2} \hat{r} \end{aligned}$$

$r > R$

as if the shell were replaced by a single charge  $Q$  located at its center ( $r=0$ ). That is,  $r$  must be measured from the center of the shell.

Sph. Shell:  $Q$  on shell



Note: As one goes from  $r < R$  to  $r > R$ , the  $\vec{E}$ -field jumps by


$$\begin{aligned} E &= \frac{Q}{4\pi\epsilon_0 r^2} \\ &= \frac{\sigma}{\epsilon_0} \end{aligned} \quad \left[ \sigma = \frac{Q}{4\pi r^2} \right]$$

Where  $\sigma$  = charge density on the surface of the shell. Crossing a sheet of charge  $\vec{E}$  jumps!

Ex5: Insulating Solid Sphere

Charge  $Q$  distributed uniformly over a sphere of radius  $R$  which is located with its center at  $r=0$ . First define charge density  $\rho = \frac{Q}{\frac{4\pi}{3} R^3}$   $[\rho = Rho]$

Again, spherical symmetry obtains about  $r=0$ .



Now, if  $r < R$ .

$$\sum_{\vec{e} \rightarrow} \vec{E} \cdot \Delta \vec{A} = E(r) 4\pi r^2$$

$$\Sigma Q_i = \rho \cdot \frac{4\pi}{3} r^3$$


so for  $r < R$ .

$$E(r) 4\pi r^2 = \frac{\rho}{\epsilon_0} \cdot \frac{4\pi}{3} r^3$$

$$\vec{E} = \frac{\rho}{3\epsilon_0} r \hat{r} \quad r < R$$

If  $r > R$  all of  $Q$  contributes so

$$\vec{E} = \frac{Q}{4\pi\epsilon_0 r^2} \hat{r} \quad r > R$$






INSULATING SPHERE UNIFORMLY CHARGED with  $\rho = \frac{Q}{\frac{4\pi}{3}R^3}$

Ex 6:

Conductor under stationary conditions: charge NOT allowed to move. If charge has to be immobile the field inside must be zero at every point. This is possible only if  $Q=0$  at every point inside the conductor. So under stationary conditions charge can reside ONLY ON the surface of the conductor consequences:

$Q$  on conducting sphere  $\equiv$  Hollow spherical charge


Further,  $E$  at surface must be perpendicular to surface otherwise charges will start moving along surface.



Notice: In both cases force on charge is outward, that is, charge is bound to the surface.

Ex 7:

Sheet of charge  $\perp$   $x$ -axis carries  $+\sigma$   $C/m^2$  of charge. Sheet located at  $x=0$ . Look at it end-on. Recall that we have shown if two equal charges are at  $+y$  and  $-y$  the  $\vec{E}$  field is purely along  $\hat{x}$ .



So here  $\vec{E}$  along  $+\hat{x}$  on right  $-\hat{x}$  on left. Choose cylinder as Gaussian Surface.

$$\begin{aligned}\sum_c \vec{E} \cdot \Delta \vec{A} &= E\pi r^2 + E \cdot \pi r^2 \\ &= E \cdot 2\pi r^2\end{aligned}$$

and

$$\sum Q_i = \sigma \pi r^2 \quad \text{[charge enclosed by cylinder]}$$

so

$$2E\pi r^2 = \sigma \cdot \pi r^2$$


$$\vec{E} = +\frac{\sigma}{2\epsilon_0} \hat{x} \quad x > 0$$

$$= -\frac{\sigma}{2\epsilon_0} \hat{x} \quad x < 0$$

Ex 7: Sheet carries  $-\sigma C/m^2$

Then 
$$\vec{E} = -\frac{\sigma}{2\epsilon_0} \hat{x} \quad x > 0$$

$$= +\frac{\sigma}{2\epsilon_0} \hat{x} \quad x < 0$$



Ex 8: Sheet at  $x=0$ ,  $\sigma C/m^2$


Sheet at  $x=d$ ,  $-\sigma C/m^2$

$$\vec{E} = 0, \quad x < 0$$


$$\vec{E} = \frac{\sigma}{\epsilon_0} \quad 0 < x < d$$

$$\vec{E} = 0 \quad x > d$$

Net  $\vec{E}$ -field:



Now the  $\vec{E}_+$  and  $\vec{E}_-$  fields will add vertically. Hence



Again  $\vec{E}$  jumps on crossing sheet of charge