

# Lecture 16 Summary

PHYS798S Spring 2016

Prof. Steven Anlage

March 31, 2016

## Ginzburg Landau Theory of Superconductors Part II

The Ginzburg-Landau (GL) theory of superconductivity is one of the most useful tools for doing quantitative calculations.

### 0.1 Boundary Conditions on the GL $\psi(r)$

What boundary conditions (BC) apply in an inhomogeneous superconductor? Enforce the condition that no super-current flows through the interface,  $\hat{n} \cdot \vec{J}_s = 0$ , where  $\hat{n}$  is unit vector in the outward normal direction from the superconductor. With  $\vec{J}_s = e^* |\psi|^2 \vec{v}_s$  one could naively let  $\psi(r)$  go to zero at the interface to satisfy the condition. However this would imply that the screening current is also zero at the interface, which is not reasonable for a superconductor/vacuum interface for example.

de Gennes came up with a more useful and flexible boundary condition. Using the expression for the current density  $\vec{J}_s = \frac{e^*}{m^*} \text{Re} \left\{ \psi^* \left( \frac{\hbar}{i} \vec{\nabla} - e^* \vec{A} \right) \psi \right\}$ , one can note that:  
 $\hat{n} \cdot \vec{J}_s = \frac{e^*}{m^*} \text{Re} \left\{ \psi^* \hat{n} \cdot \left( \frac{\hbar}{i} \vec{\nabla} - e^* \vec{A} \right) \psi \right\}$ . Now if we make  
 $\hat{n} \cdot \left( \frac{\hbar}{i} \vec{\nabla} - e^* \vec{A} \right) \psi = \frac{i}{b} \psi$ , with  $b$  real and positive, then we automatically satisfy the boundary condition.

How to interpret this constraint? In the absence of a vector potential and in one dimension, it boils down to

$\frac{\partial \psi}{\partial x}|_{x=0} = -\frac{1}{b} \psi|_{x=0}$ , where the boundary is assumed to be at  $x = 0$ . The length scale  $b$  is called the extrapolation length.

In the case of an insulator  $b = \infty$  and there is no suppression of the order parameter at the S/I interface.

In the case of a normal metal  $b$  is finite and the order parameter is suppressed at the S/N interface, linearly extrapolating to zero at a distance  $b$  into the normal metal.

For a ferromagnet, one can take  $b = 0$  so that the order parameter is suppressed

to zero at the S/FM interface.

## 0.2 GL Coherence Length

Starting from the GL equation with  $A = 0$ , one can divide through by  $\alpha$  and  $\psi_\infty$  to obtain

$$f - f^3 - \frac{\hbar^2}{2m^*\alpha} \nabla^2 f = 0, \text{ where } f = \psi/\psi_\infty.$$

The pre-factor on the Laplacian must have the dimensions of length squared, and so we define the Ginzburg-Landau coherence length as  $\xi_{GL}^2 \equiv \frac{\hbar^2}{2m^*|\alpha|}$ . As temperature approaches  $T_c$ ,  $\alpha$  goes to zero and the GL coherence length diverges.

Solutions to the GL equation:  $f - f^3 - \xi_{GL}^2 \nabla^2 f = 0$  for small perturbations from  $f = 1$  yield one-dimensional solutions of the form  $f = 1 - e^{\pm\sqrt{2}x/\xi_{GL}}$ , showing that  $\xi_{GL}$  is the "healing length" of the order parameter.

We then compared  $\xi_{GL}$  to the (temperature independent) BCS coherence length  $\xi_0 = \frac{\hbar v_F}{\pi \Delta(0)}$ . They are related as

$$\frac{\xi_{GL}}{\xi_0} = \frac{\pi}{2\sqrt{3}} \frac{\lambda_L H_c(0)}{\lambda_{eff}(T) H_c(T)}.$$

This shows that the two length scales are roughly comparable at zero temperature, at least in the clean local limit.

## 0.3 Electrodynamics in the Clean and Dirty Local Limits

We considered the Drude model for local electrodynamics in which  $J = \sigma E$  and  $\sigma = \sigma_1 - i\sigma_2$ .  $\sigma_1$  measures the dissipative part of the complex conductivity.

We found that in the clean limit  $\ell_{MFP} \gg \xi_0$  that  $\lambda_{eff}(0) \approx \lambda_L$  because almost all of the oscillator strength in  $\sigma_1$  condenses in to the delta function at zero frequency.

In the dirty limit  $\ell_{MFP} \ll \xi_0$  one finds  $\lambda_{eff}(0) \approx \lambda_L \sqrt{\frac{\xi_0}{\ell_{MFP}}}$ , and the effective screening length can be quite long. This is the case for superconductors like amorphous Mo-Ge and NbN.

## 0.4 Ginzburg-Landau $\kappa$ Parameter

The dimensionless GL  $\kappa$  is defined as

$$\kappa \equiv \frac{\lambda_{eff}(T)}{\xi_{GL}(T)}.$$

It is found that  $\kappa$  is nearly temperature independent near  $T_c$ .

Metals like Al have  $\kappa \ll 1$  and are called type-I superconductors.

Cuprates and other "high-Tc" superconductors have  $\kappa \gg 1$  and are called type-II superconductors. We shall see why these distinctions are made in the next lecture.